


AGES
8+
YEARS



aramco
FORMULA ONE™ TEAM

36V Go-Kart Installation Manual




Outdoor Use Only




WARNING

- For the safety of use, guardian must read the instructions before use.
- This package contains important information, please keep it in a safe place


PARTS



① BODY




② REAR WHEELS




③ FRONT WHEELS




④ FRONTHEAD




⑤ STEERING WHEEL



⑥ STEERING AXLE




⑦ BATTERY COVER




⑧ REAR WING SUPPORT




⑨ REAR WING



⑩ BACKREST




⑪ WHEEL COVER



⑫ FOOTREST PEDAL




CHARGER





SEAT CUSHIONS



Blister Tray




Installation steps




Remove the steering rod from the bracket for later use.
This was placed there for shipping purposes

Installation steps



Step 1



Slide the rear wheel over the rear axle, then install it using the spacer and nut. After tightening the nut, attach the wheel cover. Do this for both sides.



Step 2

Slide the spacer, front wheel, and spacer onto the front axle in sequence. Then, secure them with the nut. After tightening the nut, attach the wheel cover. Do this for both sides.



Installation steps



Step 3

Take out the bolts with butterfly nuts from the blister tray. Remove the nuts first, then pull the bumper bar outward. Line up the holes, insert the bolts, and tighten the butterfly nuts to secure.


Installation steps




Step 4

Connect the wires from the body to the front of the car, then tuck any excess wires into the body. Align the front head with the hole and secure it with 2 screws, tightening them securely.

Installation steps




After installing the steering rod, as shown in the picture.




Step 5

Hold the vehicle body steady, insert the steering rod into the front part of the car, and make sure the bent end goes through the hole in the steering rack.


Installation steps



Note: When tightening the screw, hold the nut in place and turn the bolt.





Remove nut and bolt from steering wheel column.




Step 6

Insert the steering wheel onto the steering axle, hold the steering axle from underneath the vehicle, then insert the pin and tighten the nut.



Charging Port


Portable battery compartment can be taken out and recharged




Step 7

Connect the two terminals (Power Connection)

Installation steps




Step 8
Install the battery cover and lock.




Step 9
Align the rear wing supports with the holes. Then place the rear wing onto them. Secure it with the 8 screws supplied.


Installation steps



Seat cushions are velcroed to the shown areas




Step 10
Install backrest by aligning supports with the holes on body, then using 2 screws to tighten into place.




Note: Fold up the tow wheels when not towing.

2 Rear Tow Wheels

The vehicle is equipped with 2 rear tow wheels, which allows the go-kart to be easily manouvered when lifted by the front bumper.



The body length can be adjusted to four levels. After pulling out the metal rod, align it with the hole and take out the screw rod with a nut from the blister tray and remove the nut.secure the rod with the screw. When the length is at its maximum, the footrest pedal can be placed.




⑫ Footrest Pedal

Only one side of the rod needs to be secured.



Multi-functional Music Board



Function

- A. Mode For Bluetooth
- B. Lights
- D. Turn On/off
- F. High Speed
- G. Backward
- H. Horn/volume Down
- J. Power Display
- K. Volume Display
- L. Low Speed
- N. Forward

1. Power Display

- Four bars represent full power.
- 1 bar off when the voltage is below 36V.
- 2 bars off when the voltage is below 30V.
- 3 bars off when the voltage is below 20V.
- 4 bars off when the voltage is below 14V.

2. After the startup sound completes, the device enters the waiting state.

If the startup sound has not finished, you can long press the function button to interrupt the sound.

3. Button Functions:

- A: Long press for 2 seconds to switch modes (short press has no function).
- B: Long press for 2 seconds to control the lights (short press has no function).
- D: Long press for 2 seconds to turn on/off (short press has no function).
- F: Long press for 2 seconds to drive at high speed (short press has no function).
- G: Long press for 2 seconds to go backward (short press has no function).
- H: Short press for the horn/long press to reduce volume in any mode.
- I: Long press to increase volume.
- L: Long press for 2 seconds to drive at low speed (short press has no function).
- N: Long press for 2 seconds to move forward (short press has no function).

4. If no contact is made within 30 minutes, the power will automatically shut off.

Specification

PROGRAM	DETAIL
BATTERY:	36V (18V x 2)
POWER:	324 Wh
MOTOR:	36V
TOP SPEED:	20km/h (12mph)
AGE:	96 MONTHS AND UP
MAX. USER WEIGHT:	50 KG / 110 lb
CHARGING TIME:	8-12 HOURS
CHARGER:	36V

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

To satisfy RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.


Troubleshooting Guide

Problems	Method
No Action on the Car	1.Check if the switch for each function of the vehicle is turned on. 2. Verify if the fuse has been tripped. 3. Check if the battery protection cable is disconnected. 4. Make sure the charger's DC plug is not inserted into the charging port.
Cannot Charge	Check if the charger or battery is faulty.

Maintenance

- In order to ensure that you are protected from accidental injury, please check and maintain this vehicle frequently.
- Before assembling, please check whether the boxed components are complete, if there are any parts missing, please contact us quickly.
- Regularly check whether there are loose screws or damaged parts.
- Please check regularly whether the parts are intact when they are installed or used.
- Please clean the product regularly and be careful not to damage the electrical components.
- When disassembling, please read the instruction manual carefully to avoid unnecessary damage.
- Please check the product and the charger regularly to see if the wire, plug, shell and other parts are damaged and stop using it until it is repaired.
- Only an adult who has read and understands the safety warnings may handle and operate the battery and battery charger. Keep away from children.
- Charge the battery at least once a month, even if the vehicle is not used or stored.
- Never leave the battery in a discharged state.
- Keep the charger away from water or excessive moisture to prevent short-circuiting.
- Only use the charger specified with the original item. Do not charge the battery with any other charger.
- Do not attempt to recharge non-rechargeable batteries with the original charger.
- Do not replace the battery with any other battery, or the warranty will be voided.
- Remove damaged batteries from the car immediately. Recycle or dispose of the used batteries responsibly.
- Do not short circuit the supply terminals.
- Do not leave the battery connected in the vehicle for extended periods of time when the vehicle is not being used. Disconnect the battery connector from the engine connector before storing.
- The vehicle is equipped with a thermal fuse to protect the electric circuit. If the vehicle cuts out, turn the vehicle off and on to reset.
- Regularly inspect all vehicle parts to ensure they are in good working condition.
- Regularly inspect the charger, cord, plug, and other related parts for damage.
- DO NOT operate the vehicle if there are any damaged parts. Carefully clean the vehicle with a damp cloth and mild soap. Do not get water in or near any electrical parts. Do not wash the vehicle with a hose.
- Store the vehicle indoors or use a tarp to cover it. Keep away from stoves, heaters, or other sources of heat.

Safety Belt Instructions



To fasten the seat belt correctly, place side E across the abdomen. Then, position side B and side C over the shoulders. Next, insert side A into side B, followed by side D into side C. Finally, insert both AB and CD into side E, and fasten the seat belt securely. Ensure that the seatbelt is the correct length, comfortable, and safe. Seat belts are for use only when are seated. Always fasten the seatbelt securely across the waist.



WARNING

- This machine is powered by high quality lead-acid batteries, please feel free to use it, do not drop and touch it, do not disassemble or puncture it by yourself; do not expose this product to fire, high temperature or water: if you find that the body has bulging and other undesirable phenomena, please stop using this machine.
- The assembly and adjustment of the product must be carried out by an adult, keep children away from moving parts.
- Children must be instructed by an adult to use the product and the caregiver must not leave during use, do not go near fire!
- Battery charging must be done by an adult, please charge the battery before using the product.
- Prohibit the use of any accessories not supplied by the manufacturer.
- All batteries should be loaded with the correct polarity.
- Do not let children use the charger as a toy!



WARNING

- Riding an electric product does present potential risks and caution is required. Certain conditions may cause the equipment to fail without fault of the manufacturer. Like any electric product, the Go-Kart has inherent hazards associated with its use (for example, falling off or riding it into a hazardous situation). Like any electric product, the Go-Kart can and is intended to move and it is therefore, of course, possible to lose control or otherwise get into dangerous situations. Both children and adults responsible for supervising them must recognize that if such things occur, a rider can be seriously injured, even when using safety equipment and other precautions.
RIDE AT YOUR OWN RISK AND USE COMMON SENSE.
- This manual contains important safety information. It is your responsibility to review this information and make sure that all riders understand all warnings, cautions, instructions and safety topics and assure that young riders are able to safely and responsibly use this product. We recommend that you periodically review and reinforce the information in this manual with younger riders, and that you inspect and maintain the product to ensure safety.



WARNING

- The toy must not be connected to more power sources than recommended.
- Non-rechargeable batteries must not be charged.
- The power terminals must not be short-circuited.
- Rechargeable batteries must only be charged under adult supervision.
- Different types of batteries or new and old batteries must not be mixed.



WARNING: SAFETY RIDING RULES

- **NEVER LEAVE CHILD UNATTENDED.** ALWAYS keep child in view when child is in vehicle.
Direct adult supervision is **REQUIRED**.
- **NEVER** use on roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water.
- **ALWAYS** wear shoes.
- **ALWAYS** sit on the seat.
- **NEVER** allow more than (1) rider in the vehicle.
- **RISK OF FIRE.** Do not by pass.



WARNING

The user must follow all safety rules and guidelines.

- Always use common sense and safe practices when using the vehicle. The user must be at least 8 years old.
- This product contains small parts that are for adult assembly only. Keep small children away when assembling. Remove and dispose of all protective material and plastic bags before assembly.
- Riders must always wear a fitted helmet that complies with U.S. Consumer Product Safety Commission (CPSC) Standard 16 CFR 1203.
- Do not overload the vehicle.
- Do not remove the weight restriction decals.
- Do not pull the vehicle with another vehicle or similar device.
- Keep body parts such as hands, legs, hair and clothing away from moving parts.
- Moving parts can cause serious injury.
- Use only on solid, flat, clean and dry surfaces such as pavement or level ground.
- Do not operate near streets or motor vehicles.
- Do not operate near drop-offs such as steps, steep inclines or hills. Operate on relatively level ground.
- Do not operate near water, swimming pools or other fluids.
- Do not operate in dangerous weather conditions such as rain or snow.
- Do not operate near loose dirt, mud, sand or fine gravel.
- Do not operate near flammable vapors (gasoline, paint thinner, acetone, etc.).
- Always use the vehicle in a safe, secure environment with adult supervision.
- Always wear proper protective equipment, such as an approved safety helmet (with chin strap securely buckled), elbow pads and kneepads. A helmet may be legally required by local law or regulation in your area.
- A long-sleeved shirt and long pants are recommended. Always wear shoes and keep shoelaces tied and out of the way of the wheels and drive system. NEVER RIDE BARE FOOTED OR IN SANDALS.
- Be careful and know your limitations. Risk of injury increases as the degree of riding difficulty increases.
- The rider assumes all risk associated with aggressive riding activities.
- Maintain a hold on the steering wheel at all times.
- Never carry passengers or allow more than one person at a time to ride the electric product.
- Never use near steps or swimming pools.
- Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while the motor is running.
- Do not touch the brake or electric motor on your electric product when in use as they can become very hot.
- Never use headphones, a cell phone or text when riding.
- Never hitch a ride with a vehicle.
- Before using the vehicle, the rider must understand the vehicle controls.
- It is the responsibility of the adult to educate a child and to determine if the child is capable of understanding the vehicle controls.
- An adult must ALWAYS directly supervise the use of this vehicle.
- NEVER leave a child unsupervised in the vehicle.



WARNING

Do not ride the Go-Kart in wet or icy weather and never immerse the electric product in water, as the electrical and drive components could get damaged by water or possibly create other unsafe conditions.

The electric Go-Kart is intended for use on flat, dry surfaces, such as pavement or level ground, without loose debris, such as sand, leaves, rocks or gravel. Wet, slick, bumpy, uneven or rough surfaces may impair traction, increase risks and contribute to possible accidents. Do not ride the electric product in mud, ice, puddles or water. Avoid sharp bumps, drainage grates, and sudden surface changes.

Avoid excessive speeds that can be associated with downhill rides.

Never risk damaging surfaces such as carpet or flooring by use of an electric product indoors.

Do not ride at night or when visibility is limited.



WARNING:

Practice in an open area free from obstacles until you are familiar with the brake function.

DO NOT RUN OVER ANY OBJECT AS IT COULD DAMAGE THE BRAKE OR DRIVETRAIN.



WARNING: BATTERY SAFETY

- Battery posts, terminals and related accessories contain lead and lead acid compound chemicals known to the state of California to cause cancer, reproductive harm, and are toxic and corrosive. DO NOT open the battery.



- Contact exposure to battery leakage (lead acid) may cause serious injury. Immediately contact your doctor if exposure occurs. If the chemical is on the skin, flush immediately with cool water for 15 minutes. If the chemical is swallowed, contact a medical professional immediately and seek advice.



- Tampering with or modifying the electric circuit system may cause shock, fire or explosion. It could permanently damage the system. Keep the charger housing closed to prevent exposed wiring, which may cause electric shock.



WARNING

- For the safety of use, guardian must read the instructions before use.
- This package contains important information, please keep it in a safe place

Instructions

Charging Precautions!

- When using the vehicle for the first time, you must ensure that the battery is fully charged for 12 hours, otherwise the battery may be permanently damaged and beyond repair.
- When charging, first insert the charger DC plug into the charging socket, then plug the charger into the power outlet. The toy (whole vehicle) must not be operated while the vehicle is charging.
- It is normal for the charger and the battery to be hot (below 60°C) during the charging process.
- If there is water in the connector, it can not be charged, otherwise it may cause short circuit.
- This electric vehicle must use the charger and battery equipped with this vehicle to avoid damage to the charger and battery or the circuit.

Precautions for use!

- Before use, please check whether the parts are installed in place and connected tightly.
- Do not use on streets, public transportation roads, slopes, gutters and other dangerous areas.
- Do not use on smooth floors (e.g. marble, tiles, etc.).
- Be careful not to allow children to stand on the seat.
- Do not modify the wiring of this vehicle and attach electrically charged devices.
- The charger and electric vehicle must not be allowed to get wet or used under water. Keep away from sources of ignition as far as possible to avoid damage to the electric circuit.
- When not in use, please turn off the power switch; when not used for a long time, please unplug the battery connector.

Importer of record

Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca
* faisant affaire au Québec sous
le nom les Entrepôts Costco

Importado por:
Importadora Primex S.A. de C.V.
Blvd. Magnocentro No. 4
San Fernando La Herradura
Huixquilucan, Estado de México
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
www.costco.com.mx

Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Costco Wholesale Spain S.L.U.
Polígono Empresarial Los Gavilanes
C/ Agustín de Betancourt, 17
28906 Getafe (Madrid) España
NIF: B86509460
900 111 155
www.costco.es

Costco France
1 avenue de Bréhat
91140 Villebon-sur-Yvette
France
01 80 45 01 10
www.costco.fr

Costco Wholesale Iceland ehf.
Kauptún 3-7, 210 Gardabaer
Iceland
www.costco.is

Costco Wholesale Australia Pty Ltd
17-21 Parramatta Road
Lidcombe NSW 2141
Australia
www.costco.com.au

Costco Wholesale Korea, Ltd.
40, Iljik-ro
Gwangmyeong-si
Gyeonggi-do, 14347, Korea
1899-9900
www.costco.co.kr

Costco Wholesale Japan Ltd.
2 Kakuchi, 2 Gaiku, Kaneda-Nishi
361 Urikura, Kisarazu shi
Chiba, 292-0007 Japan
0570-200-800
www.costco.co.jp

Costco (China) Investment Co., Ltd.
Room 01 Mezzanine
No. 5178, Kang Xin Highway
Pudong New District
Shanghai
China 201315
+86-21-6257-7065

Costco Wholesale New Zealand Limited
2 Guntton Drive
Westgate
Auckland 0814
New Zealand
www.costco.co.nz

Costco Wholesale Sweden AB
Box 614
114 11 Stockholm
Sweden
www.costco.se