




6V Audi R8 Spyder



Owner's Manual and Assembly Instructions

Model #: W458, 43541 47302


Read and understand the entire manual before assembly and operation. The vehicle must be assembled by an adult who has read and understands the instructions.

Made in China.

IMPORTANT:
Save this manual with your sales receipt.



If you are experiencing any difficulties with this product,
please contact Hunter Products Customer Service at
www.electricrideon.com.au
or Toll Free Number 1800 224 094 for service assistance.



Introduction

Thank you for purchasing this RollPlay vehicle. We hope the rider enjoys it for miles to come. Please read this instruction guide carefully before assembling and operating the vehicle. Please contact Hunter Products Pty Ltd at www.electricrideon.com.au or Call at 1800 224 094 with any enquiries or questions.

Specifications:

BATTERY	6V 7AH
MOTOR	6V 15W
AGE	3 Years and Up
MAX WEIGHT	35 KG (77 lbs)
PRODUCT SIZE	1.2 m x 62 x 50 cm (47.2 x 24.4 x 19.7 in.)
SPEED	4.0 km/h (2.5 MPH)
RECHARGE TIME	8-12 Hours
TYPICAL RUN TIME	1-2 Hours
CHARGER OUTPUT	DC 7.0V



WARNING!

- Non-rechargeable batteries are not to be recharged;
- Batteries are to be inserted with the correct polarity;
- Exhausted batteries are to be removed from the toy;
- The supply terminals are not to be short-circuited.
- Rechargeable batteries are only to be charged under adult supervision;
- Rechargeable batteries are to be removed from the toy before being charged;

Safety	4
Parts	6
Charging Instructions	7
Assemble the Front Wheels	8
Assemble the Rear Wheels	9
Dashboard/Windshield Assembly	10
Assemble the Steering Wheel	11
Attach the Mirrors	12
Attach the Seat	13
Operation Instructions	14
Battery Removal	15
Attach the R/C batteries	16
Remote Control Operation	17
Maintenance	19
General Care	20
Troubleshooting Guide	21
Service and Repairs	23
Warranty	24



WARNING: SAFETY RIDING RULES

The user must follow all safety rules and guidelines, or serious injury or death may occur to the user.

- Always use common sense and safe practices when using the vehicle. The user must be at least 3 years old and weigh no more than 35kg (77 lbs).
- This product contains small parts that are for adult assembly only. Keep small children away when assembling. Remove and dispose of all protective material and plastic bags before assembly.
- Riding the vehicle without a helmet. Riders must always wear a fitted helmet that complies with Australian Standard **AS/NZS 2063:2008**.
- Only sit on the seat in the vehicle.
- Do not allow more than one rider.
- Do not overload the vehicle. Do not remove the weight restriction decals.
- Do not pull the vehicle with another vehicle or similar device.
- Keep body parts such as hands, legs, hair and clothing away from moving parts. Moving parts can cause serious injury.
- Always wear shoes in the vehicle.
- Do not operate near streets or motor vehicles.
- Do not operate near drop-offs such as steps, steep inclines or hills. Operate on relatively level ground.
- Do not operate near water, swimming pools or other fluids.
- Do not operate in dangerous weather conditions such as rain or snow.
- Do not operate near loose dirt, mud, sand or fine gravel.
- Do not operate near flammable vapors (gasoline, paint thinner, acetone, etc.).
- Always use the vehicle in a safe, secure environment with adult supervision.

PREVENT INJURIES AND DEATHS:

- **NEVER LEAVE CHILD UNATTENDED. ALWAYS** keep child in view when child is in vehicle. Direct adult supervision is **REQUIRED**.
- **NEVER** use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water.
- **ALWAYS** wear shoes.
- **ALWAYS** sit on the seat.
- **RISK OF FIRE.** Do not bypass.




WARNING: BATTERY SAFETY

- Battery posts, terminals and related accessories contain lead and lead compound (acid) chemicals known to the state of California to cause cancer, reproductive harm, and are toxic and corrosive. DO NOT open the battery.



- Contact exposure to battery leakage (lead acid) may cause serious injury. Immediately contact your doctor if exposure occurs. If the chemical is on the skin, flush immediately with cool water for 15 minutes. If the chemical is swallowed, immediately give the person water or milk. Do not give water or milk if the person is vomiting or has decreased alertness. Do not induce vomiting.



- Tampering with or modifying the electric circuit system may cause shock, fire or explosion. It could permanently damage the system. Keep the charger housing closed to prevent exposed wiring, which may cause electric shock.

IMPORTANT: Before using the vehicle for the first time, the battery must be charged for a full 24 hours (no more than 30 hours).




WARNING: ADULT SUPERVISION REQUIRED

- Before using the vehicle, the rider must understand the vehicle controls and safety issues.
- It is the responsibility of the adult to educate the child and to determine if the child is capable of understanding the vehicle controls.
- An adult must ALWAYS directly supervise the use of this vehicle.
- NEVER leave a child unsupervised in the vehicle.

6 Parts

1. Car Body
2. Seat
3. Steering Wheel
4. Dashboard
5. Windshield
6. Left and Right Mirrors
7. Front Wheel (2)
8. Rear Wheel (2)
9. Hubcap (4)
10. Battery Charger
11. Steering Wheel Screw
12. Steering Wheel Nut
13. Dashboard Screw (2)
14. Snap Pin (4)
15. Large Washer (7)
16. Inner Wheel Spacer
17. Remote Controller


Not Included:



- Phillips screwdriver
- Pliers

Helpful Tip:

1. Parts 11-16 are located in the blister pack
2. Spare parts:
Large washer 2
Snap pin 2



YOU MUST CHARGE THE BATTERY FOR 24 HOURS BEFORE THE FIRST USE!

ONLY AN ADULT SHOULD HANDLE THE BATTERY AND CHARGER.


To Charge the Battery:

1. Ensure the vehicle is stopped and turned off.
2. Unlock and remove the seat.
3. Unplug the red battery connector from the red engine connector.
4. Connect the red battery connector to the red battery charger connector
5. Plug into a 240 V outlet.


To Unplug the Battery:

6. Unplug the battery charger from the outlet.
7. Unplug the red battery connector.
8. Reconnect the red battery connector to the red engine connector.
9. Replace the seat and tighten lock.


Note: It is not necessary to remove the battery for charging. However, if the battery does not reach the outlet, it can be removed for charging.



8 Assemble the Front Wheels



1. Locate the snap pins (14) and large washers (15) from the blister box. Slide the large washer (15) onto the axle
2. Slide the front wheel (7) onto the axle. Ensure that the side of the wheel with the slots is facing out
3. Slide the large washer (15) onto the axle
4. Insert the straight side of the snap pin (14) through the hole at the end of the axle to keep the wheel in place
5. Position the hubcap (9) over the holes on the wheel, and snap the hubcap into place
6. Repeat sets 1-5 for the other front wheel



Helpful Tip:

1. If you encounter trouble fitting both wheels onto the rear axle, then your rear wheel axle may need to be realigned.
2. Remove both wheels from the rear wheel axle. Using two hands, push down on the rear wheel axle and slide it gently toward the side of the vehicle that needs more room.

1. Note: The right side of the vehicle will only have 1 washer. Locate inner wheel spacer, snap pins (14) and large washers (15) from the blister box.

Left Rear Wheel


2. Slide the large washer (15) onto the axle
3. Slide the inner wheel spacer (16) onto the axle with the wide end facing out
4. Slide the left rear wheel (8) onto the axle with the gear teeth facing inward
5. Slide the large washer (15) onto the axle
6. Insert the straight side of the snap pin (14) through the hole at the end of the axle to keep the wheel in place
7. Position the hubcap (9) over the holes on the wheel, and snap the hubcap into place

Right Rear Wheel


8. Slide the right rear wheel (8) onto the axle with the gear teeth facing inward. Ensure that the gear teeth connect with the gear box that is pre-installed on the axle
9. Repeat steps 5-7

10 Dashboard/Windshield Assembly


1. Position the two front tabs on the dashboard above the slots on the windshield
2. Snap the windshield onto the dashboard
3. link the connectors assembly of car body and dashboard



1. Holding the dashboard/windshield assembly together, insert steering rod on the car body through the hole of the dashboard
2. Align the dashboard with the slots on the car, and slide the dashboard into place
3. Use a Phillips-head screwdriver to fasten the dashboard screw (13) into the two screw hole locations on either side of the dashboard




1. Use a Phillips head screwdriver to remove the screw on the battery compartment of the steering wheel
2. Insert two AAA batteries into the battery compartment
3. Replace cover and use the screwdriver to fasten



WARNING


- Do not mix old batteries with new batteries or batteries of different types.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.


1. Slide the steering wheel (3) onto the steering rod
2. Align the holes on the steering wheel with the holes on the steering rod
3. Slide the steering wheel screw (11) through the steering wheel and steering rod
4. Fasten the nut (12) to the end of the screw and tighten the screw with a screwdriver



12 Attach the Mirrors


1. Align the bottom of the mirror with the hole on the car body near the dashboard
2. Gently press the mirror down into place
3. Repeat for the other mirror






1. Ensure the lock on the car seat (2) is in the unlock position
2. Align the two hooks on the back of the car seat (2) with the holes on the back of the battery compartment
3. Insert the hooks into the holes and rotate the seat down into place
4. Use a flat head screwdriver or a coin to turn the seat to the locked position

14 Operation Instructions






1. Unlock and remove the seat
2. Disconnect the red battery connector from the red engine connector
3. Loosen and remove the screw from the battery strap using a Phillips screwdriver
4. Slide the battery strap out from the battery strap slot
5. Remove the battery

Note: It is not necessary to remove the battery for charging. However, if the battery does not reach the outlet, then it can be removed for charging.


16 Attach the R/C batteries



WARNING!


- DO NOT mix old and new batteries.
- DO NOT mix alkaline, standard (carbon-zinc), or rechargeable (nickelcadmium) batteries.

Open the battery cover. Take out the old batteries and replace with new one. Then close the battery cover. Please change the battery following step above when the red light off on R/C found.



Coding switch

Coding switch




Don't match the code when using R/C for the first time; if R/C isn't workable, then please follow the below guide to match the code.

Matching the code

Please remove the seat and find the match code button on the motor control board, then use a clip or toothpick to press the code buttons at the motor control board and on the remote-control at least 5 seconds at the same time, you will see the LED indicator on the remote control blinking, when it stops blinking and turns to light on status, it matches successfully, you can release the button now.

If it keeps blinking over 10 seconds, the match fails and the LED indicator will be off. The reason may be that the time you press the button is less than 5 seconds, or you didn't press the two buttons at the same time. To match the code again, please release the code buttons and repeat above steps.

18 Remote Control Operation



Remote –control mode :

Rider sits in the car, turns on the power switch, set the manual / remote-control switch at remote-control mode. Move the lever on the 2.4G remote-control to forward or reverse position, the car will go forward or reverse accordingly, when move the lever to left or right position, the car will go to the left or right. The car will stop if the lever released. The head-light will on when the car moves forward.

There is no need to match the code when first using the remote-control. When it happens to replace the remote-control, motor control board or mal-function of the remote-control, please match the code again as Matching code steps.

Sleep mode:

If you don't operate the car in 8 hours after you turn on the power switch, the car will shift to sleep mode automatically. If you want to use the unit, please turn the power switch off and restart it to activate.

Important Battery and Charger Information

- Only an adult who has read and understands the safety warnings may handle and operate the battery and battery charger. Keep away from children.
- Charge the battery for 24 hours before using the vehicle for the first time.
- Charge the battery immediately after each use. Charge for at least 8-12 hours, but no more than 20 hours.
- Charge the battery at least once a month, even if the vehicle is not used or stored.
- Never leave the battery in a discharged condition.
- Connect the terminal of the battery and charger, then plug the charger into a 240V AC outlet.
- It is normal for the charger to heat slightly. If the charger rises above 71°C / 160°F, disconnect the charger and call Customer Service for assistance.
- Keep the charger away from water or excessive moisture to prevent short-circuiting.
- Only use the charger specified with the original item. **Do not charge the battery with any other charger.**
- Do not attempt to recharge non-rechargeable batteries with the original charger.
- **Do not replace the battery with any other battery, or the warranty will be voided.** If you need a replacement battery, see Page 24 for replacement information.
- Remove damaged batteries from the car immediately. Recycle or dispose of the used batteries responsibly.
- Do not short circuit the supply terminals.
- Do not leave the battery connected in the vehicle for extended periods of time when the vehicle is not being used. Disconnect the battery connector from the engine connector before storing.
- The vehicle is equipped with a thermal fuse to protect the electric circuit. If the vehicle cuts out, turn the vehicle off and on to reset.

20 General Care

- Regularly inspect all vehicle parts to ensure they are in good working condition.
- Regularly inspect the charger, cord, plug, and other related parts for damage.
- Remove any damaged parts and immediately contact Customer Service for replacement parts. See Service and Repairs on Page 24 for more information.
- DO NOT operate the vehicle if there are any damaged parts.
- Carefully clean the vehicle with a damp cloth and mild soap. Do not get water in or near any electrical parts. Do not wash the vehicle with a hose.
- Store the vehicle indoors or use a tarp to cover it. Keep away from stoves, heaters, or other sources of heat.

Completely read through the manual and troubleshooting guide before contacting Customer Service at www.electricrideon.com.au or call 1800224094.

Problem	Potential Cause	Solution
Vehicle does not run	Battery is low	Recharge the battery
	Thermal fuse tripped	Reset fuse
	Snap pins are loose	Tighten snap pins
	Loose wires or loose connectors	Ensure the battery connectors are securely attached. If wires are loose, contact Consumer Service for repairs
	Battery is dead	Contact Customer Service for replacement battery
	Electrical system is damaged	Contact Customer Service for repairs
	Motor is damaged	Contact Customer Service for repairs
Vehicle only runs for a short time	Undercharged battery	Ensure a secure connection when the battery is recharging. Recharge for at least 8-12 hours
	Overcharged battery	Never charge the battery for more than 30 hours
	Battery is old	Replace battery
Vehicle runs slowly	Battery is not fully charged	Ensure a secure connection when the battery is recharging
	Battery is old	Contact Customer Service to order replacement battery
	Too much weight on vehicle	Reduce weight on vehicle 35kg (77 lbs max)
	Harsh conditions	Operate the vehicle on level ground and safe surfaces

Problem	Potential Cause	Solution
Vehicle needs a push to start	Loose wires or loose connectors	Ensure the battery connectors are securely attached. If wires are loose, contact Consumer Service for repairs
	“Dead spot” on motor	A “dead spot” means electricity is not being delivered to the terminal. Contact Consumer Service for repairs
Difficulty shifting	Attempting to shift while vehicle is moving	Stop the vehicle before shifting
Motor or gear box making grinding noises	Motor or gear damage	Contact Consumer Service for repairs
Battery will not recharge	Charger is not plugged in	Plug in the charger to a functional wall outlet
	Charger is not working	Call Consumer Service for a replacement
	Loose connector or loose adapter	Check that the connectors are securely plugged in to each other
Battery makes bubbling noise while recharging	This is normal	No action required
Charger is warm	This is normal	No action required

23 Service and Repairs

If your product requires service, repairs or replacement parts, please contact Customer Service.

Web: www.electricrideon.com.au

Or call: 1800224094

One-Year Limited Warranty

Hunter Products warrants that your Audi R8 6v will be free from defects in materials and workmanship for the vehicle (except for the 6-volt battery) for a period of 12 months, from the date of purchase. This warranty only applies where the product is completely and correctly assembled and used in accordance with all accompanying recommendations and users instructions. This warranty is in addition to your rights under the Australia Consumer Law.

Hunter Products, at its option will provide you with a refund or replacement parts for this product if the Audi R8 6v becomes defective within the warranty period. Hunter Products will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of an accident, misuse, abuse, neglect or other causes not arising out of defects in materials or workmanship, nor does it cover damages arising out of damages arising out of service by other than an authorised service person.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Please retain your receipt as proof of purchase and contact Hunter Products for further assistance on how to process any warranty claims.

Business name: Hunter Products Pty Ltd
Business address: Level 2, 424 Warrigal Road, Moorabbin VIC 3189, Australia
Telephone number: Australia wide (local call cost) 1800224 094
(Monday to Friday 8.30 to 4.30pm AES T)
Email address: www.electricrideon.com.au

This page is intentionally left blank